285X140MM
正反面印

USER INSTRUCTIONS

PORTABLE GAS GRILL
MASTER CHEF

◆ CAMPING ◆ AT THE PICNIC ◆ GO TRIP ◆ GO FISHING

RK-5103

22
PAP

Gas Type: Propane/Butane Mix
Appliance category: Direct pressure gas butane (portable gas appliance).
Min. ventilation: 5m3/h
Gas consumption: 155g/h
Gas Type: Propane/Butane
Power: 2,2 kW

Instruction for Use

OPERATION, MAINTENANCE AND INSTALLATION MANUAL
FOR DEVICE: Portable Gas Grill Master Chef

For outdoor use only! This device cannot be used on outdoor balconies, verandas or entertainment areas!
Important: Read this manual carefully to familiarize yourself with the device before connecting it to the gas cartridge
Gas Type: Propane/Butane Mix
Appliance category: Direct pressure gas butane (portable gas appliance).
Min. ventilation: 5m3/h
Gas consumption: 155g/h
Gas Type: Propane/Butane
Power: 2,2 kW
Save these instructions for future reference. This device is designed in accordance with the requirements of EN521:2019 and SAMS 1539:2017.
Device: Portable gas grill Master
Device category : Propane-butane gas under pressure.
This device can only be used with disposable metal propane-butane cartridges with threaded valves with EN 417. Attempts to mount other types of gas cartridges can be dangerous.
Use it only in well-ventilated areas to avoid unburned gas appliances.
WARNING: GAS APPLIANCES MAY ONLY BE USED IN WELL-VENTILATED AREAS
Accessible parts can be very hot. Keep younger children away from the device.

SAFETY INFORMATION

• Before connecting the gas canister to the machine, make sure it is in place and in good condition. Do not use the device if it has a damaged or worn gasket. Replace the gasket before use.
• Do not use a device that is leaking, damaged, or not working properly.
• If you suspect that the device is leaking (smell of gas), move it immediately outside to a well-ventilated area away from the flame where the leak can be found and removed. If you're looking for a leak, do it outdoors. Do not look for leaks using a flame, use soapy water for this purpose.
• If the container contains gas and cannot be ignited, the injector may be blocked. In this case, please contact your distributor.
• The device should only be used in a well-ventilated area (minimum ventilation required 500m3/h) so that official ventilation standards are met in terms of supplying enough air for combustion and avoiding the dangerous accumulation of unburned gases.
• Always use the device on a flat surface.
• Keep the device away from combustible materials during use. Use no closer than 60 cm from the wall and 120 cm from the ceiling.
• Gas cartridges must be installed or replaced in well-ventilated areas, preferably outdoors and away from any sources of ignition, such as flames, sparks, electrical fires and away from other persons.
• If the flame backs up (where the flame retracts into the nozzle outlet and ignites there), the gas supply should first be switched off immediately by closing the control valve on the device. After the device goes out, remove the gas cartridge and check the condition of the gasket. If flame If the phenomenon of flame backflow persists, contact the distributor of the product.

Instruction for Use

• Never leave your device unattended while it is turned on.
• Do not modify the device. Do not use it for purposes other than those for which it was designed.
• During periods of heating or when moving the device running, the phenomenon of a sudden increase in flame can be achieved.
• For outdoor use only.

INFORMATION FOR USE AND STORAGE

• During use, parts of the device will be hot (especially the burner). Avoid touching the hot parts with your bare hands. If you want to touch a hot device, use gloves.
• Keep small children away from the device at all times.
• Handle the device with care. Do not drop it.
• When not in use, wait for it to cool down, unscrew the gas canister from the appliance, and then store it in a cool, dry place away from heat sources.
• Always make sure that the stove has cooled completely before packing in the bag.

INFORMATION ON PREPARATION AND USE

• Before attaching the device to the threaded cartridge, make sure the seal of the machine is in place and in good condition. Perform this check every time you attach a threaded cartridge.
• Make sure the control wheel of the device is turned off (turned to the right)
• When attaching the threaded cartouche to the device, hold the cartridge vertically. Carefully screw the threaded cartridge to the device so as not to screw the thread transversely, Screw the device all the way. If you encounter resistance, do not twist further, as this could damage the threaded cartridge or threads of the device.
• Check that the device is gas-tight to the cartridge without showing any signs of leakage (check the smell of gas around the connector). If you suspect that the connection is not tight enough, wash the contacts with soap and water (the device must not be completely immersed in soapy water, as this could lead to the dangers associated with the operation of the device). In the event of a leak in the place of leakage, you will be able to notice bubbles. If you don't see any leaks, unscrew the threaded cartridge from the machine and put the device away.
• If you suspect a leak in the device during use, immediately turn off the device using the device control wheel (turn it all the way clockwise), pull the device outwards and follow the instructions (safety information).

OPERATING INFORMATION FOR THE DEVICE

• Before igniting the burner of the device, place the device on a stable horizontal surface.
• To start the burner, turn the gas regulator so that the fuel flows to the burner nozzle, and then use an external ignition source to fire the burner nozzle.
• After ignition, do not move the device during the warm-up period (1 minute), as gas from the gas cartridge can enter the device from the liquid gas canister, causing it to flare (large yellow flames). If the phenomenon of flare occurs, turn the knob reducing the flame until the flare phenomenon subsides.
• Adjust the flame size by turning the knob.
• After use, always make sure that the control wheel is completely turned off and that the device has cooled down enough to be packed.

Instruction for Use

INSTALLATION INSTRUCTIONS

• NOTE: The legs of the device are equipped with a spring mechanism. To avoid injury or damage to the Master Chef, unfolding and folding the legs must be done in a controlled manner,
• To spread the legs, put the device upside down and hold the legs to lift each of them separately. With proper unfolding, the legs will snap into the correct position.
• To fold the legs, you need to hold the leg securely and press the release clamp. Then press the legs inward into the closed position. This should be done one by one in order to achieve optimal use of space.
• Before connecting the gas supply, first make sure that the valve of the device is in the OFF position by turning the control knob clockwise.
• To mount the gas tank, check that the valve of the device is in the OFF position by turning the adjustment knob clockwise until it stops. After making sure that the gas tank is in an upright position, screw the tank to the valve by tightening it all the way by hand. If the cartridge is tightened too tightly, this may damage the gas cartridge valve.
• The device is now ready for use.

REPLACEMENT OF GAS CARTRIDGES

(Always read the gas canister marking)
• Always replace the gas cartridge outside and away from other people.
• Check if the burner flame has gone out before disconnecting the gas cartridge.
• To disconnect the gas cartridge from the machine, unscrew the gas cartridge counterclockwise.
• Check the gasket before connecting the gas cartridge to the device. It should be in place and in good condition. Do not connect the gas cartridge to the device if the gasket is damaged or worn. If in doubt, replace the gasket before use.
• When attaching the gas cartridge to the device, follow the instructions in the safety information.

USING THE DEVICE

• For outdoor use only!
• To ensure optimal operation of the device, it is necessary to protect it from wind during operation.
• Please do not move the device when it is hot. It is recommended to use protective gloves.
• NOTE: Do not expose non-stick cooking surfaces to heat when there is no food for a long time, as this may damage the non-stick coatings.
• NOTE: Easily accessible parts can be very hot. Small children must not be near the device.
•Allow the machine to cool down before packing. After cleaning:
Assemble the device as described in "installation instructions". Place the bowl/lid on the bottom of the bag. Then place the cup support in the bowl upside down. Place the grease bowl on the bowl and the bowl support upside down. Then place the device on the fat bowl upside down. Place the grid and the flat bowl in separate compartments in the flap of the bag and fasten them. Fold the flaps of the bag and fasten it.
• When the appliance is not in use, store it in a carrying bag as this prevents dirt and insects from entering the machine, which could affect the flow of gas.

Instruction for Use

• When trying to ignite the device, make sure that the gas supply from the cylinder is open before unscrewing the gas supply to the device.
• To ignite the device using piezoelectric ignition, open the control valve on the device by slowly turning it counterclockwise, and then press the piezo button at short intervals to ignite the burner. If the burner does not ignite, you should constantly press the piezo button at short intervals to ignite the burner. If the burner does not ignite, constantly press the piezo button while increasing the gas flow by unscrewing the adjustment knob until the burner ignites. If the burner does not ignite within the first 5 seconds, close the valve and wait 30 seconds before trying again.
• To ignite the device manually, light the grill lighter and slowly unscrew the counterclockwise adjustment knob until the burner ignites.
• In order to obtain a decent intensity of the flame, use the adjustment knob by unscrewing it clockwise to reduce the flame and counterclockwise to increase the flame.
• When the device is not in use, disconnect it from the gas supply.
• NOTE: When using any cooking surfaces, the flame should not be left on for more than 10 minutes, as this may damage the non-stick coatings.

MEALS:

• Master Chef has four cooking options available:
Grilling, frying, oven/wok cover and cooking.
CLEANING
Broach
• To clean the grease bowl, flat bowl and grill grate, use warm water with the addition of a non-scratching detergent, after removing excess fat after cooking.
• To remove the lid, use warm water with the addition of a non-scratching detergent.
• Do not use any scrubbing agents as they may damage the surface coating of the part.
• After removing excess grease, parts can be safely washed in the dishwasher.
Body/leg washing
• It is best to wash them with a soft, damp cloth using a gentle, non-scratching detergent. Do not wash in the dishwasher, as water could get into the valve or burner openings, which could lead to malfunctioning of the appliance.
• When cleaning the body/legs of the device, it may be necessary to remove the cup support. To do this, you need to remove the cup support from the grooves of the heat shield hitch.

ROUTINE MAINTENANCE

• To remove the gasket from the groove, use a pointed tool. Be careful not to damage the surface of the groove.
• To install a new gasket, squeeze the gasket; push one end into the guide groove; Then gently push the rest of the gasket in until it is completely fitted to the surface of the groove.
• Always keep the stove clean.