



Frame Assembly

04-07





Please Read Before You Start:

Poles are pre-inserted into the poles with Griploc clamps.
 Before erecting the frame, fully open all Griploc clamps.
 Turn the pole so that the Griploc clamp end is pointing downwards.
 This will release the pole inside.

A01	∅ 28*840mm	1
A02	∅ 28*840mm	2
A03	∅ 28*450mm	4
A04	∅ 25*200mm	3
A06	∅ 28*1000mm	8
A07	∅ 25*1000mm	3
A08	∅ 25*1000mm	3
A13	∅ 25*1000mm	2
A14	∅ 22*1000mm	2
A15	∅ 25*1000mm	2

Frame Assembly

08-10



Inner pole inside


Please Read Before You Start:

Poles are pre-inserted into the poles with Griploc clamps.
 Before erecting the frame, fully open all Griploc clamps.
 Turn the pole so that the Griploc clamp end is pointing downwards.
 This will release the pole inside.

A01	∅ 28*840mm	1
A02	∅ 28*840mm	2
A03	∅ 28*450mm	6
A04	∅ 25*200mm	3
A06	∅ 28*1000mm	8
A07	∅ 25*1000mm	3
A08	∅ 25*1000mm	3
A13	∅ 25*1000mm	2
A14	∅ 22*1000mm	2
A16	∅ 25*1000mm	2
A17	∅ 25*450mm	2

Frame Assembly

11-13




A00	∅ 28*700mm	2
A01	∅ 28*840mm	1
A02	∅ 28*840mm	2
A03	∅ 28*450mm	6
A04	∅ 25*200mm	3
A05	∅ 28*610mm	2
A06	∅ 28*1000mm	10
A07	∅ 25*1000mm	5
A08	∅ 25*1000mm	3
A13	∅ 25*1000mm	2
A14	∅ 22*1000mm	2
A16	∅ 25*1000mm	2
A18	∅ 25*700mm	2


 Inner pole inside


Please Read Before You Start:

Poles are pre-inserted into the poles with Griploc clamps.
 Before erecting the frame, fully open all Griploc clamps.
 Turn the pole so that the Griploc clamp end is pointing downwards.
 This will release the pole inside.




Frame Assembly

14-16



A00	∅ 28*700mm	2
A01	∅ 28*840mm	1
A02	∅ 28*840mm	2
A03	∅ 28*450mm	6
A04	∅ 25*200mm	3
A06	∅ 28*1000mm	12
A07	∅ 25*1000mm	5
A08	∅ 25*1000mm	5
A09	∅ 28*1000mm	2
A12	∅ 28*450mm	2
A13	∅ 25*1000mm	2
A14	∅ 22*1000mm	2
A16	∅ 25*1000mm	2
A19	∅ 25*1000mm	2




Please Read Before You Start:


Poles are pre-inserted into the poles with Griploc clamps.
 Before erecting the frame, fully open all Griploc clamps.
 Turn the pole so that the Griploc clamp end is pointing downwards.
 This will release the pole inside.

Frame Assembly

17-19



A00	∅ 28*700mm	2
A01	∅ 28*840mm	1
A02	∅ 28*840mm	2
A03	∅ 28*450mm	8
A04	∅ 25*200mm	3
A06	∅ 28*1000mm	12
A07	∅ 25*1000mm	5
A08	∅ 25*1000mm	5
A09	∅ 28*1000mm	2
A12	∅ 28*450mm	2
A13	∅ 25*1000mm	2
A14	∅ 22*1000mm	2
A16	∅ 25*1000mm	2
A19	∅ 25*1000mm	2
A20	∅ 25*450mm	2




Please Read Before You Start:


Poles are pre-inserted into the poles with Griploc clamps.
 Before erecting the frame, fully open all Griploc clamps.
 Turn the pole so that the Griploc clamp end is pointing downwards.
 This will release the pole inside.

Frame Assembly

20-22



A00	∅ 28*700mm	2
A01	∅ 28*840mm	1
A02	∅ 28*840mm	2
A03	∅ 28*450mm	6
A04	∅ 25*200mm	3
A06	∅ 28*1000mm	12
A07	∅ 25*1000mm	5
A08	∅ 25*1000mm	5
A09	∅ 28*1000mm	2
A10	∅ 28*840mm	2
A12	∅ 28*450mm	2
A13	∅ 25*1000mm	2
A14	∅ 22*1000mm	2
A16	∅ 25*1000mm	2
A19	∅ 25*1000mm	2
A21	∅ 25*1000mm	2
A22	∅ 22*1000mm	2
A23	∅ 22*1000mm	4
A24	∅ 25*1000mm	2
A25	∅ 22*450mm	2



Please Read Before You Start:

Poles are pre-inserted into the poles with Griploc clamps.
 Before erecting the frame, fully open all Griploc clamps.
 Turn the pole so that the Griploc clamp end is pointing downwards.
 This will release the pole inside.